




Proudly built in the USA

Owner's Manual

TC-508

Dumping Flatbed



TruckCraft Corporation

Chambersburg, PA

1-800-755-3867

Copyright 2011

www.truckcraft.com

TRUCKCRAFT CORPORATION

5751 Molly Pitcher Hwy. S.

Chambersburg, Pa. 17202

Tel. 800.375.3867

Phone 717.375.2900

Fax 717.375.2975

www.truckcraft.com



"WHERE WORKMANSHIP IS EVERYTHING"

Table of Contents

Preface.....1

Ordering Repair Parts.....1

Safety Information.....2

Mounting and operating Instructions.....3

Maintenance.....6

D1-06088 Assembly on SRW Ford7

D2-06084 Mounting Kit Installation / Ford9

D1-06194 Assembly on SRW GM 10

D2-06222 Mounting Kit Installation / GM 12

Options:

D2-06106 Pintle Hitch/Bumper Installation / Ford 13

D2-06231 Pintle Hitch/Bumper Installation / GM 14

D1-06198 12” Fold Down Sides 15

Warranty17

Preface

Read and understand all sections of this manual prior to installing or operating the TruckCraft dump bed. This manual contains information for the installation, operation, and maintenance of the TruckCraft dumping flatbed with fold down sides. Proper care and operation of the unit will assure years of dependable service. Your local TruckCraft Dealer will instruct you in its general operation. TruckCraft Corporation will be glad to answer any questions that may arise regarding the operation of your dump bed.

Ordering Repair Parts

When service is necessary, your local TruckCraft dealer can provide assistance. Always obtain original TruckCraft replacement parts from your dealer. Substitute items could affect the performance and warranty of the unit. Dealers in your area can be found on the web at **www.truckcraft.com**.

When ordering parts the dump bed serial number and description or part number of parts needed are required. **The serial number is located on front plate (behind the cab) of the cabguard on the drivers side.**

Dumper Serial Number: _____

Date of Purchase: _____

Purchased From: _____

TruckCraft Telephone #800.375.3867 or 717.375.2900

TruckCraft Fax #717.375.2975

Method of shipping parts to be specified such as customer pickup, UPS, Common Carrier, Parcel Post or Air Freight. All orders to be confirmed in writing, or faxed, to insure proper understanding of request.

Having preventative maintenance parts on hand could save valuable time.

Improvements and Changes

Because TruckCraft strives to continually improve our products, we reserve the right to make changes and improvements wherever practical, without obligation to make those same changes or improvements to the equipment already sold. Photographs used in this manual may not be up-to-date with current design changes.

Safety Information

Observe the following safety procedures during the use of the dumper: Before operating read and understand all information furnished with your dumper and in this manual.

- ✓ Keep hands, feet and clothing away from moving parts.
- ✓ Never exceed the structural capacity (7,000 lbs.) of the dumper. Structural capacity means the maximum weight the dumper will carry and dump with an acceptable margin of safety. This does not mean that your truck can carry 7,000 lbs.
- ✓ Never exceed the manufacturer's GVWR (Gross Vehicle Weight Rating) of your truck. This rating can usually be found on the end of the driver's door just above or below the latch.
- ✓ Never exceed the truck axle and tire ratings.
- ✓ Always keep as much of the load as possible forward of the rear axle and evenly distributed from side to side.
- ✓ Never work under a raised body unless the body is supported by blocking or propped in the raised position. Always unload the body prior to using the prop.
- ✓ Operate the dumper only when the truck is on a firm, level surface.
- ✓ Always inspect the area around the truck for safe dumping prior to operating.
- ✓ Do not move the truck with the deck in a raised position.
- ✓ Never let the dumper sit with the bed raised when not in use.
- ✓ Always open the tailgate prior to raising the dumper when it is loaded.
- ✓ Store the remote control in a location that assures that no object can come in contact with the raise button unintentionally.
- ✓ Before raising the dumper, check for adequate overhead clearance. Be alert for overhead electrical wires.
- ✓ Regularly check and tighten all fasteners to the recommended torque values in the Torque Chart shown below.
- ✓ Maximum hydraulic pressure is factory set . Tampering with this setting will void the warranty and can damage hydraulic components and result in system failure.
- ✓ Do not attempt to repair this dumper yourself unless you have experience working on dump beds and are familiar with the hazards involved. For safety, take your dumper to the dealer from which it was purchased for all repairs and service.

Torque Chart - Steel Fasteners		
Size	Grade 5 (Lb-Ft)	Grade 8 (Lb-Ft)
1/4-20	6-7	10-11
1/4-28	8-9	11-12
5/16-18	14-15	21-22
3/8-16	24-26	37-40
1/2-13	60-65	90-100
5/8-11	122-130	180-190
3/4-10	220-230	315-330



FIGURE 1

Mounting & Operation Instructions

CAUTION: Verify any lifting and support devices used can support the Flatbed assembly before picking it up.

1. Install the mounting kit on the truck frame per drawing #D2-06084. Use the hardware supplied with the mounting kit and torque bolts as noted.
2. Attach a jumper cable to the flatbed subframe and to the frame of the truck for a temporary ground.
3. Cut and remove the shipping strap (if any) at the front of the flatbed and temporarily hook the loose end of the power cable to the positive terminal of the truck battery.
4. Position the flatbed dumper in the approximate mounting location. Center the bed from side to side.
5. While making sure everybody is standing clear, raise the flatbed high enough to engage the safety prop. Use the up and down buttons on the remote control to raise and lower the flatbed (See figure #3). Lower the flatbed while holding the prop in a vertical position so that it engages a slot in the bottom of one of the floor planks and is supporting the full weight of the flatbed.
6. Mount the flatbed and subframe to the truck frame Mount Kit per drawing #D1-06088 Section G-G and Section H-H. Use the mounting hardware supplied with the kit and per the bill of material on D1-06088. When tightening bolts, do not over-tighten the three bolts attaching the subframe at the rear of the deck, which can crush the aluminum tube.

Figure 3



CAUTION: Do not work under the flatbed dumper without having the safety prop properly positioned. (See figure #4).

Safety prop raised and shown engaged in slot in floor plank.

7. Route the pump power cables to the battery in such a way as to ***avoid sharp edges and maintain a minimum distance of 8” from any portion of the exhaust system.*** By routing the power cable along the side of the truck frame, you will give the cable maximum protection. Fasten the cable to the truck frame using the stay straps provided. These stay straps should be inserted through holes in the truck frame to secure the cable. Do not cross under or over the truck frame where the cable could get pinched or frayed due to rubbing.
8. The hydraulic pump reservoir has been filled at the factory. If more fluid is necessary use only Dextron Automatic Transmission Fluid. **CAUTION:** Do not overfill. Adding too much fluid will cause the reservoir to overflow when the bed is lowered. The best method of refilling the reservoir is to place the dumper on the safety prop, with the prop being as straight up and down as possible under the dumper. Insert a clean ruler or measuring stick into the reservoir making sure it touches the bottom of the reservoir, not the pickup tube. Add fluid until the depth of fluid in the reservoir is 4”. If you have no way to measure 4”, an alternate method of filling is to add 2-3 oz. of fluid at a time and raise the bed. Repeat this procedure until the pump does not change sound (from pumping air) at the end of its stroke. Leave the breather off and fully lower the bed to the down position. The bed can then be raised and the breather reinstalled. The reason for leaving the breather off during the first cycle after filling is to guard against pressurizing the reservoir in the event that it has been overfilled. Back pressure due to overfilling may dislodge the reservoir from the pump. Adding too much fluid will result in the reservoir overflowing when the bed is lowered. The hydraulic cylinder will require bleeding of all air each time you replenish fluid.

CAUTION: An accumulation of air in the lifting cylinder will cause the bed to bounce and possibly raise when the vehicle is moving.

BLEEDING THE CYLINDER: After filling the hydraulic reservoir to the proper level, locate and remove the plug on the top of the hydraulic cylinder. Place a clean rag over the plug opening and jog the “UP” button until a small amount of fluid comes out the opening. Replace the plug and re-check the reservoir fluid level as described above. If the fluid level is low, repeat all steps listed above.

9. Install the remote control in the cab by making note of the wire colors and connection locations prior to disconnecting the remote cable from the power unit. Then route the end of the cable through the floor of the pickup cab behind the driver’s seat (preferably through a rubber plug in the floor). The cable should then be routed down to the power unit where it should be reconnected. Use a stay strap to secure the cable to the front of the bottom subframe to assure clearance when the flatbed dumper is raised and lowered.

10. **Never exceed the manufacturer's gross vehicle rating of the truck.** These ratings can usually be found on the end of door just above or below the latch on the driver's side. Filling the bed with materials such as sand, stone, scrap steel, etc. could exceed the rating of the Flatbed dumper and would extremely overload the truck. Filling the bed without regard to the weight of the material being loaded can result in structural failure and injury. Never exceed the dumper and trucks maximum ratings.

Have questions? Call Toll Free 1-800-375-3867

Maintenance


1. Check the hydraulic fluid level and bleed the cylinder every 6 months. If additional fluid is required add Dextron Automatic Transmission Fluid. The fluid should not need to be changed unless it becomes contaminated from an outside source. To **check the fluid level and bleed the cylinder** follow step #8 in the "Mounting and Operating Instructions".
2. Never operate the vehicle if any "bounciness" or "springiness" is noted in the empty flatbed dumper when fully down. The cylinder may have air trapped inside that could cause the empty flatbed to bounce up into oncoming high wind, thus raising the dumper while moving. **BLEED THE CYLINDER IMMEDIATELY.** Follow the directions in step #8 in the "Mounting and Operating Instructions".
3. Never close off the cab guard window screen when the bed is empty . High winds and high driving speed may cause the bed to raise.
4. Lubricate the stainless steel tailgate pins periodically with WD-40.
5. Depending on frequency of use, check all bolts for proper tightness and torque.

REV	DESCRIPTION	DATE
B	P5-05010 nut was p4-00469	2/16/2012

#	PIN	Rev Qty	Name	Material	Weight
26	I5-06122	- 1	Manual, TC-508		0.00 lbm
27	P4-00561	2	Hex Head Cap Screw	.38-16 X .75 18-8 SS	0.08 lbm
28	P4-00562	3	Hex Hd Cap Screw - .38-16 X1.0 SS	.38-16 X 1.00 18-8 SS	0.15 lbm
29	P4-00567	5	Nyl. Insert Lock Nut - .38-16 SS.	.38-16 18-8 SS.	0.12 lbm
30	P4-00570	4	Flat Washer - .38 SS	.38 18-8 SS	0.03 lbm
31	P4-00571	6	Flat Washer / MS15795 - .75 SS	Stainless Steel, 304,.75"	0.26 lbm
32	P4-00620	4	Flat Washer - .50 SS	.50 18-8 SS	0.06 lbm
33	P4-00689	4	Hex Hd Cap Screw - .50-13 X 1.25 SS	.50-13 X 1.25 18-8 SS	0.45 lbm
34	P4-00835	2	Hex Head Cap Screw	.38-16 X 1.50 18-8 SS	0.13 lbm
35	P4-01264	- 3	Cotter Pin - S.S.	.31 Dia x 1.25 Lg. 18-8 SS	0.06 lbm
36	P4-03267	5	Hex Head Cap Screw	.63 - 11 x 3.5" ZP, Grade 8	1.92 lbm
37	P5-05010	5	Nyl. Insert Lock Nut/GR 8	.63-11 ZP Steel/Gr 8	0.46 lbm
38	P5-05013	14	Flat Washer-Hardened-5/8	ZP Steel/69 ID x 1.31 OD x .122 Thk	0.48 lbm
39	P5-05630	- 1	Elbow-37 Degree x ORB	Brennan #6801-06-08-NWO-FG	0.24 lbm
40	P5-05680	- 1	Cap, Square - Solenoid Cover	1.75 sq. vinyl/Mc#9092K72	0.01 lbm

#	PIN	Rev Qty	Name	Material	Weight
1	A4-00312	A 1	Cyl. Pin	304 S. S. - .875 Dia. x 3.5 Lg.	0.58 lbm
2	A4-00546	2	Bearing	Purchased Part	0.01 lbm
3	A4-00547	- 2	Bearing-.88 ID x 1.0 OD x 1.0 Lg.	Iglide #GSI-1416-16	0.01 lbm
4	A4-00548	2	GLIDE Bearing, 1.00"	Purchased Part	0.08 lbm
5	A4-00611	- 1	Hyd. Hose .38 JIC Swivelx36"		0.72 lbm
6	A4-01300	9	Grommet, 2.5"	Purchased	0.43 lbm
7	A4-01400	A 1	Decal, Manual	Vinyl w/ Adhesive Backing	0.01 lbm
8	A4-01401	- 1	Decal / Serial #	Purchased Part	0.00 lbm
9	A4-02254	1	Decal / Warning / Caution	Purchased Part	0.03 lbm
10	A4-03313	A 1	Braided Duplex Cord/4 GAX16'-4"/Bl-Rd		7.03 lbm
11	A4-04459	- 7	Light, Clearance	2.50 Dia. LED Red Light	1.08 lbm
12	A4-04460	- 2	Light, Clearance	2.50 Dia. LED Yellow Light	0.31 lbm
13	A4-04684	- 2	Decal / Danger Crush. Hazard	Purchased Part	0.06 lbm
14	B4-00192	A 2	Bearing Block	Alum, 6061-T6 .75 x 2.5 x 3.0	0.92 lbm
15	B4-00329	A 4	Plate-Mounting TC-120	.38"or.25"x4.0"x4.0"6061-T6 Al. R5-00343orR5-01049	2.34 lbm
16	B4-04077	2	Medium LOGO / Plastic	Purchased	0.00 lbm
17	B4-04135	- 1	Hyd. Ftg.-Elbow 90	Steel - .38 JIC X #6 SAE	0.14 lbm
18*	C4-01353	1	Harness- Flatbed	Purch. - Elect. Wiring Harness	1.50 lbm
19	D2-06084	E 1	Installation-Ford Frame Adapter /TC-508		131.89 lbm
20	See Notes	C 1	Base Frame Weld./TC-101, I21 & 508/Std.		62.99 lbm
21	D3-06082	- 1	Weld. - Deck & Cabguard		413.52 lbm
22	D4-05629	- 1	Hydraulic Pump/Tank #M-3519-0303		36.65 lbm
23	D4-05882	- 1	Pivot Pin / .75 OD x 46.88"lg / Deck Box	304 SS, .75 Dia x 46.88 Lg.	5.96 lbm
24	D4-05985	- 1	Telescopic Cyl.-TC-101 & I21	HDM # 030111A	52.00 lbm
25	D4-06141	- 1	Caution/Capacity Decal - TC-101	Vinyl	0.01 lbm

Notes:
Drawing is for DI-06088 & DI-06195.
BIM change as follows:
Item 20 Base Frame Weldment P/N
D3-05262 for 100" Deck/56" CA/DI-06088
D3-05513 for 80" Deck/40" CA/DI-06195




1. FINISH ALL WELDS, CHAMFER OR
ROUND CORNERS
2. DIMENSIONS UNLESS OTHERWISE
SPECIFIED
3. DIMENSIONS TO CENTER UNLESS
OTHERWISE SPECIFIED
4. DIMENSIONS TO FACE UNLESS
OTHERWISE SPECIFIED
5. DIMENSIONS TO CENTER UNLESS
OTHERWISE SPECIFIED
6. DIMENSIONS TO FACE UNLESS
OTHERWISE SPECIFIED
7. DIMENSIONS TO CENTER UNLESS
OTHERWISE SPECIFIED
8. DIMENSIONS TO FACE UNLESS
OTHERWISE SPECIFIED
9. DIMENSIONS TO CENTER UNLESS
OTHERWISE SPECIFIED
10. DIMENSIONS TO FACE UNLESS
OTHERWISE SPECIFIED
11. DIMENSIONS TO CENTER UNLESS
OTHERWISE SPECIFIED
12. DIMENSIONS TO FACE UNLESS
OTHERWISE SPECIFIED
13. DIMENSIONS TO CENTER UNLESS
OTHERWISE SPECIFIED
14. DIMENSIONS TO FACE UNLESS
OTHERWISE SPECIFIED
15. DIMENSIONS TO CENTER UNLESS
OTHERWISE SPECIFIED
16. DIMENSIONS TO FACE UNLESS
OTHERWISE SPECIFIED
17. DIMENSIONS TO CENTER UNLESS
OTHERWISE SPECIFIED
18. DIMENSIONS TO FACE UNLESS
OTHERWISE SPECIFIED
19. DIMENSIONS TO CENTER UNLESS
OTHERWISE SPECIFIED
20. DIMENSIONS TO FACE UNLESS
OTHERWISE SPECIFIED
21. DIMENSIONS TO CENTER UNLESS
OTHERWISE SPECIFIED
22. DIMENSIONS TO FACE UNLESS
OTHERWISE SPECIFIED
23. DIMENSIONS TO CENTER UNLESS
OTHERWISE SPECIFIED
24. DIMENSIONS TO FACE UNLESS
OTHERWISE SPECIFIED
25. DIMENSIONS TO CENTER UNLESS
OTHERWISE SPECIFIED
26. DIMENSIONS TO FACE UNLESS
OTHERWISE SPECIFIED

TRUCKCRAFT

5751 Molly Pitcher Highway
Chambersburg, PA, 17201
717-375-2900
717-375-2905
FAX 717-375-2975

TITLE: TC-508/SRW Ford
SCALE: None
DATE: 12/17/2010
MATERIAL: None
APPR. BY: GertYL
DWG. NO: DI-06088
SHEET 1 OF 2
REV: B

#	P/N	Qty	Name	Weight	#	P/N	Qty	Name	Weight
1	A4-00312	1	Cyl. Pin	0.58 lbm	26	5-06122	1	Manual, TC-508	
2	A4-00546	2	Bearing	0.01 lbm	27	P4-00469	5	Hex Flange Nut	0.50 lbm
3	A4-00547	2	Bearing--88 ID x 1.0 OD x 1.0 Lg.	0.01 lbm	28	P4-00561	2	Hex Head Cap Screw	0.08 lbm
4	A4-00548	2	IGLIDE Bearing, 1.00"	0.08 lbm	29	P4-00562	3	Hex Hd Cap Screw - 38-16 X1.0 SS	0.15 lbm
5	A4-00611	1	Hyd. Hose .38 JIC Swivel x .36"	0.72 lbm	30	P4-00567	5	Nyl. Insert Lock Nut - 38-16 SS	0.12 lbm
6	A4-01300	9	Grommet, 2.5"	0.43 lbm	31	P4-00570	4	Flat Washer - .38 SS	0.03 lbm
7	A4-01400	1	Decal, Manual	0.01 lbm	32	P4-00571	6	Flat Washer / MS15795 - .75 SS	0.26 lbm
8	A4-01401	1	Decal / Serial #	0.00 lbm	33	P4-00620	4	Flat Washer - .50 SS	0.06 lbm
9	A4-02254	1	Decal / Warning / Caution	0.03 lbm	34	P4-00689	4	Hex Hd Cap Screw - 50-13 X 1.25 SS	0.45 lbm
10	A4-03313	1	Braided Duplex Cord/4 GAX16-4"/BL-Rd	7.03 lbm	35	P4-00835	2	Hex Head Cap Screw	0.13 lbm
11	A4-04459	7	Light, Clearance	1.08 lbm	36	P4-01264	3	Cotter Pin - S.S.	0.06 lbm
12	A4-04460	2	Light, Clearance	0.31 lbm	37	P4-03267	5	Hex Head Cap Screw	1.92 lbm
13	A4-04684	2	Decal / Danger Crush, Hazard	0.06 lbm	38	P5-05013	11	Flat Washer--Hardened-5/8	0.38 lbm
14	B4-00192	2	Bearing Block	0.92 lbm	39	P5-05630	1	Elbow--37 Degree x ORB	0.24 lbm
15	B4-00329	3	Plate-Mounting TC-120	1.76 lbm	40	P5-05680	1	Cap. Square - Solenoid Cover	0.01 lbm
16	D4-05985	1	Telescopic Cylinder, TC-120	52.00 lbm					
17	B4-04077	2	Medium L060 / Plastic	0.00 lbm					
18	B4-04135	1	Hyd. Fig.-Elbow 90	0.14 lbm					
19	C4-01353	1	Harness-Flatbed	1.50 lbm					
20	D2-06222	1	Installation-GM Frame Adapter/TC-508	105.46 lbm					
21	D3-05262	1	Base Frame Weld/TC-101, 121 & 508/Std.	62.99 lbm					
22	D3-06082	1	Weld - Deck & Cabguard	373.56 lbm					
23	D4-05629	1	Hydraulic Pump/Tank #M-3519-0303	36.65 lbm					
24	D4-05882	1	Pivot Pin / .75 OD x 46.88"lg / Deck Box	5.96 lbm					
25	D4-06141	1	Caution/Capacity Decal - TC-101	0.01 lbm					






 TRUCK CRAFT COMPANY, INC.
 1701 IMPERIAL HWY
 CHANDLER, AZ 85226
 PHONE: 480-948-0000
 FAX: 480-948-0000
 E-MAIL: SALES@TRUCKCRAFT.COM

MODEL: TC-508/SRW GM
 SERIAL: 41182011
 NAME: [Blank]
 SHEET 1 OF 2



WEIGHT: 695.24 lbm
 PART NO: DI-06194



TRUCKCRAFT
 TRUCKCRAFT CORPORATION
 1700 IMPERIAL AVENUE
 CHICAGO, IL 60628
 PHONE: 773-592-1000
 FAX: 773-592-1000
 E-MAIL: SALES@TRUCKCRAFT.COM



MODEL: TC-508/SRW GM
 SERIAL: 01182011
 PART NO: 696248
 SHEET 2 OF 2
 DATE: 01-06-194

#	P/N	Qty	Name	Weight
1	P5-05012	32	Flat Washer-Hardened	1.34 lbm
2	P5-05102	6	Hex Head Cap Screw	2.83 lbm
3	P4-00469	16	Hex Flange Nut	1.61 lbm
4	D3-06155	1	Front Frame Weldment/GM	50.66 lbm
5	D3-06224	1	Frame Mount, Mid/GM	1.83 lbm
6	D3-06152	1	Rear Frame Mount/GM	25.85 lbm
7	P4-00468	10	Hex Head Cap Screw	2.32 lbm




DETAIL A

Top surfaces of tubes and Rear Frame Mount must all be at same elevation for subframe to lay across them. Shim as required.



DETAIL B



DETAIL D



Dr. .66 Dia. (21/32) holes for 62 Dia. bolts as required. Some existing holes may need to be enlarged.



 TRUCKCRAFT
 170 IMPERIAL HWY
 ONONDAGA, NY 13691
 FAX 716 291 2191



Installation-GM Frame Adapter (TC-508)
 Name: 2/28/2011
 SHEET 1 OF 1

#	P/N	Qty	Name	Weight
1	P5-05184	2	Cap, 2.0 x 3.0 Tube	0.07 lbm
2	D4-06094	2	Shim, Bumper Mount	0.38 lbm
3	P5-06325	1	License Plate Light Holder	0.05 lbm
4	P4-00886	2	Pan Head Machine Screw	0.02 lbm
5	P4-00845	2	Flat Washer	0.01 lbm
6	P5-26323	1	License Plate Light	0.12 lbm
7	P4-00887	2	Nyl. Insert Lock Nut - #10-32	0.01 lbm





TRUCK CRAFT
 170 IMPERIAL HWY
 OKMONT, AL 35091
 PHONE: 205-890-8800
 FAX: 205-890-8801

Partie Hitch Bumper Assy/TC-508-Ford 11135 lbm
 Name: None
 DATE: 7/14/2011
 SHEET 1 OF 1 PART NO: D2-06106




Install tailgate locking pins and mounts per detail D. Use the locking pins to position the tailgate on the corner weldments. Install hinges and use as a template to drill 4 - .41 Dia. (1 3/32) holes thru rear rub rail. Attach hinges with called out hardware.


After installing corner weldments in flatbed pockets, position rack sides using the .06" and .34" dimensions shown in details A & B. Mount hinges and pins. Using the hinges as a template, drill 12 - .41 Dia. (1 3/32) holes thru the rub rail and attach the hinges to the deck with the hardware called out.



DETAIL A



DETAIL B



DETAIL C

TRUCKCRAFT
 170 IMPACTWAY AVENUE
 CHICAGO, IL 60641
 PHONE: 773-291-8800
 FAX: 773-291-8895

ASSY: Fold Down Sides/12 TTC-508
 PART NO. 12/2/2011
 SHEET 1 OF 2

TRUCKCRAFT
 170 IMPACTWAY AVENUE
 CHICAGO, IL 60641
 PHONE: 773-291-8800
 FAX: 773-291-8895

DATE: 7/26/2011
 DRAWING NO. 15
 SHEET 1 OF 2

Warranty

TruckCraft Corporation warrants each **Flatbed Dumper** to be free from defects in material and workmanship for a period of **Two Years** from the date of sale to the original retail purchaser and agrees only to repair or replace at its own expense, any part or parts of the product found to be defective in material or workmanship, provided TruckCraft is notified of such defect or defects within the **Two Year** warranty period and given reasonable time to correct the defect.

Installation and operation of the product must be in accordance with TruckCraft's instructions. Repairs required following operation beyond the rated capacity or improper use or application of any products shall not be considered defects within the scope of the foregoing warranty. Warranty will not be considered on any altered, modified, or misused part and failures due to lack of maintenance or accidents. Warranty claims by the user must be made to the dealer from which the product was purchased, unless otherwise authorized by TruckCraft. This warranty does not cover the shipping costs of defective parts to or from the dealer. No claims for labor shall be considered unless preauthorized by TruckCraft. No dealer has authority to make any representation or promise on behalf of TruckCraft, or to alter or modify the terms or limitations of this warranty.

TruckCraft Corporation

5751 Molly Pitcher Hwy. S., Chambersburg, PA 17201

Printed in U.S.A.
© 2010 TruckCraft Corp.